


# **ahead RC** Crawler

## U452 Sideboard Flatbed

### Assembly Manual



## Required tools and hardware

### Tools

- 1.5mm Hex Driver
- 2.0mm Hex Driver
- 2.5mm Hex Driver
- Needle Nosed Pliers
- Instant Glue
- Hot Glue

### Electronics

- 5mm LED White x2
- 5mm LED Red x2
- 5mm LED Orange x2



### Hardware

Hardware	Quantity	Check
M2*5 Socket head	8	
M2*8 Socket head	52	
M2*10 Socket head	10	
M2*20 Socket head	2	
M3*5 Socket head	20	
M3*10 Socket head	18	
M3*16 Socket head	4	
M3*20 Socket head	9	
M3*10 Countersunk (CS)	2	
M3*16 Countersunk (CS)	4	
M3*20 Countersunk (CS)	12	
Chassis mount screws: original length +12mm	4	
8x2mm magnet	4	
12x2mm magnet	4	



## Before you begin



- Be sure to read through the manual and familiarise yourself with the instructions
- Visualise a plan to assemble all the pieces
- Make sure you have all of the hardware and tools
- Be sure to have enough instant glue
- Dry fit all parts before painting and assembling



Tip: It will help to paint all of the parts before final assembly







Repeat on  
the other side





















Body is now fully complete. Thank you for selecting ahead RC products.

If you have any questions or need help with the assembly, please do not hesitate to contact us at:

[aheadrc@gmail.com](mailto:aheadrc@gmail.com)

or visit us at:

[www.aheadrc.com](http://www.aheadrc.com)