

ahead RC Crawler Cat 1

Expedition Cab

Assembly Manual



Required tools and hardware

Tools

- 1.5mm Hex Driver
- 2.0mm Hex Driver
- 2.5mm Hex Driver
- Needle Nosed Pliers
- Instant Glue
- Hot Glue

Electronics

- 3mm Orange LED x6
- 5mm White LED x2
- 5mm Red LED x2
- 5mm Orange LED x2

Hardware


Hardware	Quantity	Check ✓
M2*5 Socket head	1	
M2*10 Socket head	26	
M3*10 Socket head	19	
M3*15 Socket head	18	
M3*15 Button head (BH)	12	
M3*10 Countersunk (CS)	31	
M3*3 Grubscrew (GS)	1	
M3 lock nut	24	



Before you begin

- Be sure to read through the manual and familiarise yourself with the instructions
- Visualise a plan to assemble all the pieces
- Make sure you have all of the hardware and tools
- Be sure to have enough instant glue
- Dry fit all parts before painting and assembling


Tip: It will help to paint all of the parts before final assembly

Combining and assembling the split cab









Mounting the fenders




**If using wide track fenders: Use
M3x15mm x18**



Assembling the rear of the cab















Adding accessories
















Mounting the front panel of the cab





Body is now fully complete. Thank you for selecting ahead RC products.

If you have any questions or need help with the assembly, please do not hesitate to contact us at:

aheadrc@gmail.com

or visit us at:

www.aheadrc.com

Best of luck with your build!