

ahead RC Crawler

V303 TRX4M

Assembly Manual



Required tools and hardware

Tools

- 1.5mm Hex Driver
- 2.0mm Hex Driver
- Needle Nosed Pliers
- Instant Glue
- Hot Glue

Electronics

- 3mm LED White x3
- 3mm LED Red x2
- 3mm LED Orange x2



Hardware



Hardware	Quantity	Check
M2*5 Socket head	44	
M2*8 Socket head	21	
M2*8 Socket head (for wheels)	24	
M2*10 Socket head	2	
M2*16 Socket head	2	
M2.5*20 Socket head	4	
10x2mm magnet	10	



Before you begin



- Be sure to read through the manual and familiarise yourself with the instructions
- Visualise a plan to assemble all the pieces
- Make sure you have all of the hardware and tools
- Be sure to have enough instant glue
- Dry fit all parts before painting and assembling




Tip: It will help to paint all of the parts before final assembly


































Repeat on the
other side



Repeat on the
other side





Body is now fully complete. Thank you for selecting ahead RC products.

If you have any questions or need help with the assembly, please do not hesitate to contact us at:

aheadrc@gmail.com

or visit us at:

www.aheadrc.com